



8" TFT/LCD 2 DIN NAVIGATION DVD RECEIVER

SEAT LEON 11> - ALTEA 11>

SKODA FABIA 07> - ROOMSTER 07> - OCTAVIA 07>

VOLKSWAGEN CADDY 10> - GOLF V - GOLF VI - MAGGIOLINO - PASSAT 05>
PASSAT CC 08> - POLO 09> - SCIROCCO 08> - SHARAN 10> - TIGUAN - TOURAN

CONNESSIONI-FUNZIONI

CONNECTIONS-FUNCTIONS


CONNEXIONS-FONCTIONS

KABEL-VERBINDUNGEN-FUNKTIONEN

CONEXIONES-FUNCIONES

VM 081

CONNESSIONI • CONNECTIONS • CONNEXIONS • KABEL-VERBINDUNGEN • CONEXIONES



Collegamento da effettuare solo con retrocamera installata.
To connect with rear camera installed only



1. Accende / Spegne / Menu
Torna al menu principale
2. Radio
3. Vol. +
4. Vol. -
5. Microfono
6. Silenzia audio
7. DVD
8. Navigazione
9. Espulsione disco
10. Reset
11. Slot SD Card navigazione
12. Feritoia inserimento disco
13. Slot SD Card

1. On / Off / Menu
Return to Main Menu
2. Radio
3. Vol. +
4. Vol. -
5. Microphone
6. Mute
7. DVD
8. Navigation
9. CD-Eject
10. Reset
11. Navigation-SD-Slot
12. CD-slot
13. SD Card-slot

1. Allume / S'éteint / MENU
Retourne au menu principale
2. Radio
3. Vol. +
4. Vol. -
5. Microphone
6. Réduit au silence l'audio
7. DVD
8. Navigation
9. Expulsion disque
10. Reset
11. Slot SD Card navigation
12. Fente insertion disque
13. Slot SD Card

1. EIN / AUS / MENÜ
Zurück zum Hauptmenü
2. Radio
3. Vol. +
4. Vol. -
5. Mikrofon
6. Stummschaltung
7. DVD
8. Navigation
9. CD-Auswurf
10. Reset
11. Navigations-SD-Öffnung
12. CD-Einwurf
13. SD-Öffnung

1. Enciende / Apaga / MENU
Vuelve al menú principal
2. Radio
3. Vol. +
4. Vol. -
5. Micrófono
6. Silencia audio
7. DVD
8. Navegación
9. Expulsión disco
10. Reset
11. Ranura tarjeta de navegación
12. Ranura introducción disco
13. Ranura tarjeta de memoria SD Card



Via F.lli Cervi, 167/C • 42124 Reggio Emilia (Italy) • Tel. ++39 0522 941621 • www.phonocar.com • e-mail: info@phonocar.it