

## CONNESSIONI • CONNECTIONS CONNEXIONS • KABEL-VERBINDUNGEN CONEXIONES

# BMW

S.3 (E46) '98>'05


Con navigatore / With navigator • Senza / Without Bose system

MANUALE ISTRUZIONI • INSTRUCTIONS MANUAL • NOTICE DE MONTAGE ET D'EMPLOI  
GEBRAUCHSANWEISUNGEN • MANUAL DE INSTRUCCIONES

## VM088C

Via F.lli Cervi, 167/C • 42124 Reggio Emilia (Italy) • Tel. ++39 0522 941621 www.phonocar.com • e-mail:info@phonocar.it

### FUNZIONI • FUNCTIONS • FONCTIONS • FUNKTIONEN • FUNCIONES



1. Menù
2. Radio
3. Impostazioni audio
4. Luminosità
5. On - Off / Volume
6. Slot SD Card navigazione
7. Reset
8. Slot SD Card multimedia
9. Seek+/Seek-
10. Bluetooth
11. DVD
12. Navigazione
13. Espulsione disco
14. IR
15. Feritoia inserimento disco
16. Microfono

1. Menu
2. Radio
3. Audio settings
4. Brightness
5. On - Off / Volume
6. Navigation-SD Card-slot
7. Reset
8. Multimedia-SD Card-slot
9. Seek+/Seek-
10. Bluetooth
11. DVD
12. Navigation
13. Expell-CD
14. IR
15. CD-opening
16. Microphone

1. Menu
2. Radio
3. Paramètres audio
4. Luminosité
5. On-Off / Volume
6. Slot SD Card navigation
7. Reset
8. Slot SD Card multimedia
9. Seek+/Seek-
10. Bluetooth
11. DVD
12. Navigation
13. Ejection disque
14. IR
15. Fente insertion disque
16. Microphone

1. Menu
2. Radio
3. Audio-Einstellungen
4. Helligkeit
5. On - Off / Lautstärke
6. Navigations-SD-Öffnung
7. Reset
8. SD-Öffnung
9. Seek+/Seek-
10. Bluetooth
11. DVD
12. Navigation
13. CD-Auswurf
14. IR
15. CD-Öffnung
16. Mikrofon

1. Menu
2. Radio
3. Ajustes de audio
4. Brillo
5. Volumen-Encendido / Apagado
6. Ranura SD Card navegación
7. Reset
8. Ranura SD Card
9. Seek+/Seek-
10. Bluetooth
11. DVD
12. Navegación
13. Expulsión disco
14. IR
15. Ranura introducción disco
16. Micrófono

