



**7" TFT/LCD
2 DIN NAVIGATION
DVD RECEIVER**


FORD

C-MAX >'11 - FOCUS '04>'11 - GALAXY '07> - MONDEO '08>

**CONNESSIONI-FUNZIONI
CONNECTIONS-FUNCTIONS
CONNEXIONS-FONCTIONS
KABEL-VERBINDUNGEN-FUNKTIONEN
CONEXIONES-FUNCIONES**

VM 085

CONNESSIONI • CONNECTIONS • CONNEXIONS • KABEL-VERBINDUNGEN • CONEXIONES



FUNZIONI • FUNCTIONS • FONCTIONS • FUNKTIONEN • FUNCIONES



1. DVD
2. Equalizzatore
3. Vol. +
4. Vol. -
5. Silenzia audio
6. Reset
7. Porta SD Card per navigazione
8. Porta SD Card audio/video
9. Ingresso Aux-in
10. Seek- ricerca stazioni
11. Seek+ ricerca stazioni
12. Radio
13. Navigazione
14. Porta mini USB
15. Espulsione disco
16. Feritoia inserimento disco
17. Cambio sorgente

1. DVD
2. Equalizer
3. Vol. +
4. Vol. -
5. Mute
6. Reset
7. SD-slot or navigation
8. Audio/Video-SD-port
9. AUX-IN-Input
10. Seek- Research Stations
11. Seek+Research Stations
12. Radio
13. Navigation
14. Mini-USB-port
15. CD-Eject
16. CD-port
17. Change Source

1. DVD
2. Egaliseur
3. Vol. +
4. Vol. -
5. Réduit en silence l'audio
6. Reset
7. Porte SD Card pour la navigation
8. Porta SD Card audio/vidéo
9. Entrée Aux-in
10. Seek- recherche stations
11. Seek+ recherche stations
12. Radio
13. Navigation
14. Porte mini USB
15. Expulsion disque
16. Fente insertion disque
17. Change la source

1. DVD
2. Equalizer
3. Vol. +
4. Vol. -
5. Stummschaltung
6. Reset
7. SD-Öffnung für Navigation
8. Audio/Video-SD-Öffnung
9. AUX-IN-Eingang
10. Seek- Sendersuche
11. Seek+ Sendersuche
12. Radio
13. Navigation
14. Mini-USB-Öffnung
15. CD-Auswurf
16. CD-Öffnung
17. Quelle wechseln

1. DVD
2. Ecuualizador
3. Vol. +
4. Vol. -
5. Silencia audio
6. Reset
7. Ranura tarjeta de Navegación
8. Ranura tarjeta de memoria audio/video
9. Entrada Aux-in
10. Seek- búsqueda emisoras
11. Seek + búsqueda emisoras
12. Radio
13. Navegación
14. Puerto mini USB
15. Expulsión disco
16. Ranura introducción disco
17. Cambio fuente

